

BEFORE YOU START:

1 Use our BB Compatibility Charts to determine the correct BB for your frame - PF41/42, PF46, BSA and T47.

2 Determine the overall width of the BB when installed in the frame.

3 Use this chart to assess the chainline and clearance requirements for your bike/needs.

CRANK	FULLY ASSEMBLED BB WIDTH	CRANKSET AXLE LENGTH	CHAINRING/SPIDER OFFSET	CHAINLINE SINGLE*	CHAINLINE DOUBLE		REAR HUB SPACING	Q-FACTOR	CLEARANCE A	CRANKSET PART REFERENCE	NON-DRIVE SIDE AXLE SPACER	DRIVE SIDE AXLE SPACER
					INNER	OUTER						
	91	127.5	STANDARD	45	39.5	46.5	130	149	60.5	HCRXN [70/72/75] [B/C/N/PU/R/S]	NONE	NONE
		133.5	STANDARD	47.5	42	49	135/142	154	63	HCRXWN [70/72/75] [B/C/N/PU/R/S]	2.75mm	2.75mm

* FOR SPIDER WITH SINGLE RING AND SPIDERLESS

