

BEFORE YOU START:

1 Use our BB Compatibility Charts to determine the correct BB for your frame - PF41/42, PF46, BSA and T47.

2 Determine the overall width of the BB when installed in the frame.

3 Use this chart to assess the chainline and clearance requirements for your bike/needs.

CRANK	FULLY ASSEMBLED BB WIDTH	CRANKSET AXLE LENGTH	CHAINRING/SPIDER OFFSET	CHAINLINE	Q-FACTOR	CLEARANCE A (to rubber boot)	CRANKSET PART REFERENCE	NON-DRIVE SIDE AXLE SPACER	DRIVE SIDE AXLE SPACER
	96.5	138.5	STANDARD	49	168	68.5	HCCN73 [55/65/70] [B/C/N/PU/R/S]	NONE	NONE
			BOOST	52	168	68.5	HCCN73 [55/65/70] [B/C/N/PU/R/S]	NONE	NONE
		144	STANDARD	52	174	71.5	HCCN73W [55/65/70] [B/C/N/PU/R/S]	2.75mm	2.75mm
			BOOST	55	174	71.5	HCCN73W [55/65/70] [B/C/N/PU/R/S]	2.75mm	2.75mm

