



HUB	DISC SIDE		NON DISC SIDE	
	Part No.		Part No.	
Pro 5 6B Front (all shell widths)	HTT194	Pro 5 Front Bearing Press Tool	HTT194	Pro 5 Front Bearing Press Tool
Pro 5 CL Front (all shell widths)	HTT194	Pro 5 Front Bearing Press Tool**	HTT194	Pro 5 Front Bearing Press Tool**
Pro 5 6B Rear (all shell widths)	HTT196	Pro 5 Rear Bearing Press Tool Short	HTT195	Pro 5 Rear Bearing Press Tool Long
Pro 5 CL Rear (all shell widths)	HTT196	Pro 5 Rear Bearing Press Tool Short**	HTT195	Pro 5 Rear Bearing Press Tool Long**
HG Freehub	HTT197	Pro 5 Freehub Bearing Press Tool Long	HTT199	Pro 5 Freehub Bearing Press Tool Short 11spd
XD Freehub	HTT197	Pro 5 Freehub Bearing Press Tool Long	HTT198	Pro 5 Freehub Bearing Press Tool Short MS/XD
MS Freehub	HTT197	Pro 5 Freehub Bearing Press Tool Long	HTT198	Pro 5 Freehub Bearing Press Tool Short MS/XD

*All tools included in Pro 5 Tool Kit HTTPRO5

**Tool used on small end for CL hubs