


































DETERMINE THE TYPE OF YOUR BB SHELL	MEASURE THE BB SHELL FRAME WIDTH	CRANK SPINDLE DIAMETER	SELECT YOUR BB MODEL			DETERMINE SPACER USAGE		ASSEMBLE BOTTOM BRACKET AS SHOWN BELOW	DUB CONVERSION AVAILABLE	TRUVATIV GXP CONVERSION AVAILABLE	
			FULLY ASSEMBLED WIDTH	NON-DRIVE SIDE	DRIVE SIDE	NON-DRIVE SIDE	DRIVE SIDE				
BSA THREADED	68mm	24mm	ROAD		BBSSRSN (Black) Other colours are available		1 x 1mm (BBSP105)	1 x 1mm (BBSP105)	NDS  DS	✗	✓ BBSP109
			MTB		BBSSXCN (Black) Other colours are available		1 x 2.5mm (BBSP106)	2 x 2.5mm (BBSP106) or 1 x 2.5mm and E-type derailleur bracket	NDS  DS	✗	✓ BBSP109
		30mm	ROAD		BBSS30N (Black) Other colours are available		1 x 1mm (BBSP105)	1 x 1mm (BBSP105)	NDS  DS	✓ BB016 - K1	✗
			MTB		BBSS30N (Black) Other colours are available		1 x 2.5mm (BBSP106)	2 x 2.5mm (BBSP106)	NDS  DS	✓ BB016 - K1	✗
	73mm	24mm		BBSSXCN (Black) Other colours are available		-	1 x 2.5mm (BBSP106) or E-type derailleur bracket	NDS  DS	✗	✓ BBSP109	
		30mm		BBSS30N (Black) Other colours are available		-	1 x 2.5mm (BBSP106)	NDS  DS	✓ BB016 - K1	✗	
	83mm	24mm		BBSSDHN (Black) Other colours are available		1 x 2.5mm (BBSP106)	2 x 2.5mm (BBSP106) or 1 and E-type derailleur bracket	NDS  DS	✗	✓ BBSP109	
		30mm		BBSS30N (Black) Other colours are available		1 x 2.5mm (BBSP106)	2 x 2.5mm (BBSP106)	NDS  DS	✓ BB016 - K1	✗	
	100mm	24mm		BBSSFATN (Black) Other colours are available		1 x 2.5mm (BBSP106)	2 x 2.5mm (BBSP106)	NDS  DS	✗	✓ BBSP109	
		30mm		BBSS30N (Black) Other colours are available		1 x 2.5mm (BBSP106)	2 x 2.5mm (BBSP106)	NDS  DS	✗	✗	
	120mm	24mm		In Development					✗	✗	
		30mm		BBSS30N (Black) Other colours are available		1 x 2.5mm (BBSP106)	2 x 2.5mm (BBSP106)	NDS  DS	✗	✗	

BEFORE YOU START:

1 You will need to know the following information to correctly determine the bottom bracket for your needs.

<p>BB Shell Type</p> <ul style="list-style-type: none"> » BSA Threaded » Press Fit Ø46mm » Press Fit Ø42mm » Press Fit Ø41mm » T47 Threaded 	<p>BB Width</p> <p>Measure the dimension over the full width of the frame at the BB. Frame sizes can vary a little but should be ±1mm from one of the sizes detailed in the table inside.</p>	<p>Crankset Axle</p> <p>You will need to know the axle diameter, the main sizes are:</p> <p>24mm 29mm 30mm</p>
---	--	---

2 You should also check you have the required axle length on your crankset to suit the installed over bearing width of the bottom bracket once installed on your frame. Crank axle types usually fall into the following groups:

Road: To suit 91mm over bearing width. **MTB:** To suit 96.5mm over bearing width.

MTB DH: To suit 111.5mm over bearing width. **FATBIKE 100:** To suit 128.5mm.

FATBIKE 120: To suit 148.5mm.