


RX

hope



CAUTION: READ THIS BEFORE INSTALLING YOUR CRANKS!

Riding bicycles can be dangerous. These instructions should be read thoroughly before installation. Failure to follow these instructions before installing and using Hope Technology Components can result in severe injury or death.

BOX CONTENTS

- Non drive side crankarm sub-assembly
- Drive side crankarm sub-assembly (with or without spider)
- Chainring bolts and pedal washers
- Spider lockring tool - HC105-26T

TOOLS REQUIRED

10mm hex, 2.5mm hex, Torque Wrench

HOPE WARRANTY

All Hope Technology Components are covered for two years from original date of purchase against manufacturer defects in material and workmanship. Proof of purchase is required. Product must be returned to the original retailer to process any warranty claim. This warranty does not cover any damage caused through mis-use or failing to comply by the recommendations given in this manual. This warranty does not affect your statutory rights.

HOPE TECHNOLOGY
(IPCO) Limited

Hope Mill, Calf Hall Road
Barnoldswick, Lancashire
BB18 5PX, United Kingdom

T: 01282 851400 - E: info@hopetech.com - W: hopetech.com

PRELIMINARY CHECKS

001_ Firstly make sure you are using the right bottom bracket for the crankset - the bearing internal diameter must be 30mm diameter.

002_ The other critical dimension is the over bearing width (D in diagram) of the bottom bracket once fitted to the frame. This should measure 91mm +/- 1mm Hope manufacture a range of bottom brackets to allow fitment of the RX crank into almost every bottom bracket shell.

INSTALL SPIDER / SPIDERLESS CHAINRING AND CHAINRING

If not already installed, install the crankset spider or spiderless chainring as follows:

003_ Make sure the drive side crankarm to spider interface is clean, free of dust and dirt. Apply a small amount of grease on the spline and thread.

004_ Install the spider or spiderless chainring onto the driving spline, making sure the orientation of the spider is correct. Fit the lockring shim and engage the lockring by hand on the first threads. Do not use the lockring tool at this point, the lockring should thread oneasily just using your fingers.

005_ Finally using the specifc lockring tool (ref HC105-26T), tighten the lockring. To do so you can either use a standard BB spanner, 38mm socket or place the tool upside down in a vice. Recommended tightening torque: **50-60 N.m**

006_ Following manufacturer instructions, at this point install the chainring onto the spider. The spider is optimised for single ring use but can also be used in a double ring set-up, consult the seperate chainline document. A single ring should be fitted to the outside face of the spider. Chainring bolts recommended tightening torque: **10-12 N.m**


INSTALL NON DRIVE SIDE SUB ASSEMBLY

007_ Apply grease on the bearing contact surface of the shaft and bearing inner race.

008_ Make sure the bearing preload nut is fully screwed on so that there is no gap between the bearing preload ring and the non drive side crankarm.


009_ Slide the sub assembly in to the bottom bracket from the non drive side of the bike. The shaft should slide in easily by hand.

DO NOT USE A HAMMER!




Traduction Française
Deutsche Übersetzung


001





002




005



006



008



009

HOPETECH.COM



INSTALL DRIVE SIDE CRANKARM

010_Apply grease to the shaft spline and slide the drive side arm on making sure it is positioned **180 degrees** from non drive side arm!

011_Using a 10mm hex, screw the crank bolt into the axle thread. Take care to get the thread started correctly before fully tightening. The bolt should turn freely and draw the crank onto the first part of the spline with minimal resistance.

012_Fully tighten the crank bolt, drawing the crank onto the axle spline. The further the crank is drawn onto the spline the more torque will be needed to turn the crank bolt. The crankarm will come to a solid stop against the shaft angled shoulder when properly located.
Crank bolt recommended tightening torque: **50N.m**

PRELOAD THE BEARINGS

IMPORTANT: Do not use any tool to tighten the bearing preload nut. This would overload the bearings and lead to premature wear.

013_Unscrew the preload screw by hand until it comes into contact with the bottom bracket bearing shield.

014_There should be no visible gap between the preload nut and the bearing shield.









015_Using a 2.5mm hex, tighten the preload nut pinch bolt. Recommended tightening torque: **0.6-0.8 N.m**

016_Check that there is no side play in the crankset assembly and that the bottom bracket can spin freely.

PEDAL WASHERS


IMPORTANT: Please follow relevant manufacturers instructions for pedal installation. Pedal washers are provided to avoid damaging the crankarm. Some pedal axle designs have an integrated washer, in this case washers are not required.

When using the pedal washers take care to centre the washer in the counter bore, not doing this could cause damage to the crankarm.




DISASSEMBLY PROCEDURE

001_001_Using a 10mm hex turn the crank bolt on the drive side crank arm anticlockwise to loosen it.



002_Keep turning the bolt in an anticlockwise direction, it will go loose and then you will feel resistance as the crank starts to extract off the axle, keep turning until the drive side crank comes right off the axle.



003_Slide the non drive side crank assembly out of the bottom bracket.

004_Loosen the bearing preload nut pinch bolt using a 2.5mm hex and fully screw the nut on so that there is **no gap** between the bearing preload ring and the non drive side crankarm.