



















DETERMINE THE TYPE OF YOUR BB SHELL	MEASURE THE BB SHELL FRAME WIDTH	CRANK SPINDLE DIAMETER	SELECT YOUR BB MODEL			DETERMINE SPACER USAGE		ASSEMBLE BOTTOM BRACKET AS SHOWN BELOW	DUB CONVERSION AVAILABLE	TRUVATIV GXP CONVERSION AVAILABLE	
					FULLY ASSEMBLED WIDTH	NON-DRIVE SIDE	DRIVE SIDE				
T47 THREADED	68mm	24mm	ROAD		In Development				✗	✗	
			MTB		In Development				✗	✗	
		30mm	ROAD		BBT476830SSN (Black) Other colours are available		1 x 1mm (BB018-05)	1 x 1mm (BB018-05)	NDS  DS	✓ KIT 001	✗
			MTB		BBT476830SSN (Black) Other colours are available		1 x 2.5mm (BB018-04)	2 x 2.5mm (BB018-04)	NDS  DS	✓ KIT 001	✗
	73mm	24mm		In Development					✗	✗	
		30mm		BBT476830SSN (Black) Other colours are available		-	1 x 2.5mm (BB018-04)	NDS  DS	✓ KIT 001	✗	
	86.5mm	24mm		In Development					✗	✗	
		30mm		BBT478630SSN (Black) Other colours are available		1 x 2.5mm (BBSP106)	2 x 2.5mm (BBSP106)	NDS  DS	✓ KIT 004	✗	
	89.5mm	24mm		In Development				NDS	✗	✗	
		30mm		BBT478630SSN (Black) Other colours are available		-	1 x 2.5mm (BB018-04)	NDS  DS	✓ KIT 004	✗	
	92mm	24mm		In Development					✗	✗	
		30mm		BBT478630SSN (Black) Other colours are available		1 x 2.5mm (BBSP106)	2 x 2.5mm (BBSP106)	NDS  DS	✓ KIT 004	✗	

WORKSHOP GUIDE | T47 THREADED BOTTOM BRACKET

BEFORE YOU START:

1 You will need to know the following information to correctly determine the bottom bracket for your needs.

BB Shell Type

- » BSA Threaded
- » Press Fit Ø46mm
- » Press Fit Ø42mm
- » Press Fit Ø41mm
- » T47 Threaded

BB Width

Measure the dimension over the full width of the frame at the BB. Frame sizes can vary a little but should be ±1mm from one of the sizes detailed in the table inside.

Crankset Axle

You will need to know the axle diameter, the main sizes are:

24mm | 29mm | 30mm

2

You should also check you have the required axle length on your crankset to suit the installed over bearing width of the bottom bracket once installed on your frame.

Crank axle types usually fall into the following groups:

- Road:** To suit 91mm over bearing width. **MTB:** To suit 96.5mm over bearing width.
- MTB DH:** To suit 111.5mm over bearing width. **FATBIKE 100:** To suit 128.5mm.
- FATBIKE 120:** To suit 148.5mm.